



UNIVERSAL GROINKIT



POSITIONING MEASUREMENTS

POSITIONING MEASUREMENTS

ELEVATION



***The total rise is measured from the top of the groin vault strut (including the thickness) down to the tip.**